



a xylem brand

YSI P700 IQ Orthophosphate Analyzer Orthophosphate Measurement for the IQ SensorNet System



The P700 for orthophosphate measurement can be used as a stand alone analyzer or networked with other sensors in an IQ SensorNet network. Use the P700 throughout the wastewater plant from pre-sedimentation to biological tanks to the effluent. The P700 provides continuous data to help operational efficiency improvement decisions and phosphate elimination verification.

Parameters:

Orthophosphate

Applications:

Wastewater treatment (municipal and industrial); pre-sedimentation, aeration, post-sedimentation, effluent

- Compact design - pump for permeate supply is integrated in the analyzer housing
- Simple system configuration with the IQ SensorNet; measure additional parameters in addition to orthophosphate
- Low reagent consumption - exchange solutions on average every 4-8 months, reduces overall cost vs. other analyzers
- Automatic or manual calibration (adjustable)
- Automatic cleaning function (adjustable)
- Uses proven Vanadomolybdate (yellow) method of detection
- Wide measuring range - two measuring ranges allow the P700 to be used in a wide range of locations throughout the WWTP
- Indoor or outdoor versions available with heating or cooling



The P700 filter mounted inside a tank. Easy to clean with water and a brush, bleach, or hydrochloric acid.

Technical Information for Filtration

Membrane Surface Area (standard filter)	393.7 in ² (1000 cm ²)
Max. Operating Temperature	113°F (45°C)
Max. Immersion Depth	15.75 in (40 cm)
Max. Suction Height	196.85 in (5 m)
Materials	Housing: PVC; Seals: NBR; Screws: Stainless Steel

P700 IQ Technical Specifications

Measurement Method	Vanadomolybdate (yellow)
Measurement Range PO ₄ -P	Range A: 0.05 to 15.00 mg/L; Range B: 1 to 50 mg/L
Resolution PO ₄ -P	Range A: 0.01 mg/L; Range B: 1 mg/L
Accuracy PO ₄ -P	Range A: ±2% or ±0.05 mg/L, whichever is greater; Range B: ±2% or ±1 mg/L, whichever is greater
Measurement Range PO ₄	Range A: 0.15 to 46.00 mg/L; Range B: 3 to 153 mg/L
Resolution PO ₄	Range A: 0.01 mg/L; Range B: 1 mg/L
Accuracy PO ₄	Range A: ±2% or ±0.15 mg/L, whichever is greater; Range B: ±2% or ±3 mg/L, whichever is greater
Response Time T-90	< 5 minutes
Detection Limit	Range A: 0.05 mg/L PO ₄ -P; Range B: 1 mg/L PO ₄ -P
Calibration	Automatic (adjustable) or manual
Dimensions	~26.69 x 30.71 x 15.55 in (~678 x 780 x 395 mm)
Weight	~66 lbs (~30 kg); without reagents
Measuring Interval	Range A: 5 minutes (adjustable) or greater; Range B: 10 minutes or greater
Cleaning Solution	1,000 mL for 4 months with cleaning every 24 hours
Climate Control	Heating, Cooling (fan)
pH range	5 to 9 pH units
Operating Temperature	-20 to 40°C (-4 to 104°F) for outdoor unit; 15 to 40°C (59 to 104°F) for indoor unit
Storage Temperature	-20 to 50°C (-4 to 122°F)
Sample Temperature	4 to 45°C (39 to 113°F)
Reagent Consumption	2500 mL for 8 months with measuring range A and 10 minute measuring interval 2500 mL for 4 months with measuring range B and 10 minute measuring interval
Equipment Safety, Standards	EN 61010-1; UL 3111-1; CAN/CSA C22.2 No. 61010.1
Electrical	115 VAC
Certifications	CE, IP54, UL
Outputs	Relays, analog outputs, various communication protocols, interfaces directly with IQ SensorNet controllers

P700 IQ Orthophosphate Ordering Information*

Item #8P-000Y	P700 IQ-I115 Orthophosphate analyzer P700 IQ, indoor, 115 V **
Item #8P-001Y	P700 IQ-O115 Orthophosphate analyzer P700 IQ, outdoor for climate control, 115 V **
Item #8P-010Y	P700 IQ-PI115 Orthophosphate analyzer P700 IQ with permeate pump for filtration, indoor, 115 V**
Item #8P-011Y	P700 IQ-PO115 Orthophosphate analyzer P700 IQ with permeate pump for filtration, outdoor for climate control, 115 V**
Item #821 988Y	Rail mount for P700 IQ
Item #821 989Y	Wall mount for P700 IQ
Item #821 991Y	Stand mount for P700 IQ
Item #821 987Y	Filter membrane module with premounted membrane
Item #821 972Y	Set of 2 filter membranes for filter membrane module (821987Y) and module case (821973Y)
Item #821 973Y	Module case for filter membranes. Includes module case without filter membranes (order filter membranes separately)
Item #821 971Y	Standard solution 0.0 mg/L PO ₄ -P (zeroing) for P700 IQ (1.0 L)
Item #821 997Y	Standard solution 1.6 mg/L PO ₄ -P for P700 IQ (1.0 L)
Item #821 996Y	Standard solution 8.0 mg/L PO ₄ -P for P700 IQ (1.0 L)
Item #821 995Y	Standard solution 20.0 mg/L PO ₄ -P for P700 IQ (1.0 L)
Item #821 998Y	Cleaning solution for P700 IQ (1.0 L)
Item #821 999Y	Reagent for P700 IQ for orthophosphate measurement (2.5 L)

* Additional accessories, such as tubing, available at YSI.com/PO4 **Power supply not included. Order items separately.

Visit YSI.com/IQ for additional information on the IQ SensorNet system.

YSI

1725 Brannum Lane, Yellow Springs, OH 45387
Tel +1 937.767.7241 800.897.4151 (US)
info@ysi.com
YSI.com @YSlinc [facebook.com/myYSI](https://www.facebook.com/myYSI)

YSI is a registered trademark.
Specifications are subject to change. Please visit YSI.com to verify all specs.
©2017 YSI, a xylem brand
■ Printed in the USA. W105-03 August, 2017



a xylem brand