

YSI 9300 / 9500 reagent instructions

Fluoride (YAP179L)

On the 9300 and 9500 photometers, fluoride test samples will be run on the **Phot 14** test program following the YAP179L instructions outlined below.

Select fluoride program:

1. Choose "Phot 14" from the main menu.

Prepare your blank

2. Add 10 mL of sample to photometer tube
3. Insert into the cell holder and "Blank"

Prepare your sample

4. Add 4 drops of Fluoride liquid reagent and stir to mix
5. Add 1 Fluoride No 2 tablet. Crush and stir
6. Place sample into the cell holder
7. Set timer to 5 minutes, then Exit and Read. Timer will count down and read out an F mg/L value.