

# EMM25 Sonde Spar

DESIGNED FOR RAPID DEPLOYMENT, EVENT MONITORING AND EASY USE

Looking for a cost effective way to deploy a water quality sonde? The EMM25, Sonde Spar is designed to be a low cost option for short and long-term monitoring. It's simple to use design allows for rapid deployment for event monitoring and emergency response. The lightweight design allows for the system to be deployed by a single person; it can be deployed from a small boat or from shore. The integral deployment tube will accept any YSI EXO or 6-Series sonde or 3rd party device

Available options for the EMM25 Sonde Spar include an amber, self-contained flashing beacon for deployments in navigable waters. Bluetooth connectivity for remote data access from a compatible Bluetooth enabled device.

## Features Include:

- Low-Cost Option for Short-Term and Long-Term Monitoring
- Single-Person Deployment
- Designed for Rapid Deployment
- Event Monitoring, Emergency Response
- Works with YSI EXO & 6-Series Sonde and 3rd Party Devices
- Lockable Well Cap for secure deployments
- Indestructible buoy hull survives impact, punctures and vandalism
- Won't warp, dent or crack through normal use
- Uniform color doesn't require regular maintenance
- Through-hull penetration for monitoring equipment makes routine servicing simple, fast and secure
- Standard configuration available with short lead time.



## Available Options

- Beacon
- Bluetooth Radio



SL-15-Y  
SoaLite



xylem  
Let's Solve Water

# EMM25 Sonde Spar Specifications



"Standard System Configuration Shown"

## EMM25 Specifications

Hull Material	4PCF Softlite® Ionomer foam body
Weight	25lbs.
Shape	Spar
Dimensions	Hull 10" O.D. x 27" Length Overall Length .....
Mooring Attachment	Single-Point Galvanized 1/2-inch chain
Deployment Tube	Integral for any YSI Exo or 6-Series Sonde or 3rd party device

## Available Options

Bluetooth	Class 1 Radio 65 meter Range Class 1 dongle included 6 Alkaline C batteries 30 days power @ 2x per week collection
Beacon	Up to 2nm LED Self-Powered IP68 Rated Polycarbonate Integral Bird Spike



"EMM25 Buoy deployed in retention pond measuring DO"

\*Shown with optional beacon\*



[www.xyleminc.com](http://www.xyleminc.com)

YSI Integrated Systems & Services Inc.  
9843 18th Street North, Suite 1200  
St. Petersburg, FL 33716  
O: +1 727.565.2201  
[www.ysisystems.com](http://www.ysisystems.com)